


WPC GARDEN SHEDS INSTALLATION MANUAL FOR H008-B




Contents














1. Contents	_____	Page 01
2. Installation Requirement	_____	Page 02
3. List of components	_____	Page 03~04
4. Variation 1: Install of the canopy on the right side	_____	Page 05~32
5. Variation 2: Install of the canopy on the left side	_____	Page 33~60
6. The installation of window fastener	_____	Page 61~62
7. Optional accessory: Gutter System	_____	Page 63~66

Installation Requirement :


































When do the assembling of a garden shed, a hard and flat ground without slope is needed. Please also make sure that the installation site has a good ventilation and drainage condition.








































When dealing with any type of construction project, it is necessary to wear appropriate safety equipment to avoid any risk of injuries. We recommend but not only limited to the following safety equipment when handling, cutting, and installation : gloves, eye protector, respirator, long sleeves and pants.

Impact electric drill 	Cutting machine 	Electric screwdriver 	Riveting gun 	Tape & Hammer 
Levelling Instrument 	L-square 	Safety helmet 	Goggles 	Work clothes 
gloves 	protective shoes 	Ladder 		

List of components

WP1 x41 + spare 1  L=2800mm	WP2 x2  L=2723mm	WP3 x14  L=2560mm	WP4 x6  L=985mm	WP5 x26  L=685mm
WP6 x2  L=2800mm	WP7 x1  L=3006mm	WP68 x4  L=1140mm	UC-008  UC008-1 645mm x2 UC008-2 658mm x6 UC008-3 646mm x2 UC008-4 625mm x1 UC008-5 626mm x1	
AP1 x1  L=2723mm	AP2 x1  L=3006mm	TP1 x1  L=3300mm	TP2 x29 + spare 1  L=3300mm	TP3 x1  L=3300mm
BF1 x2  L=2885mm	BF2 x1  L=2840mm	BF3 x1  L=2840mm	BF4 x1  L=2565mm	
MF1 x1 	MF2 x1 	MF3 x1 	MF4 x1 	MF5 x1 
PO1 x1  L=2404mm	PO2 x1  L=2254mm	ST1 x2 	MF20 x1 	OT-5 x2 + spare 1 
DF1 x1  L=1965mm	DF2 x1  L=1965mm	DF3 x1  L=1500mm	DF4 x1  L=1430mm	DP-6 x1 


List of components

TF1 x3  L=3300mm	TF2 x3  L=2620mm	TF3a, TF3b 1+1  L=3280mm	TF4 x1  L=3300mm	TF5 x1  L=3300mm
TF6 x1  L=2740mm	TF7 x1  L=2740mm	TF8 x4 	other spare parts x5  x2  x1 	
CL-1 x3 	CL-2 x1 	CL-3 x8 	CL-4 x32 + spare 2 	CL-5 x2  L=780mm
CL-6 x6  L=200mm	CL-7 x4  L=300mm	CL-8 x4 	CL-9 x4 + spare 2 	Drill 1 , Drill 2 1+1   Ø2.8 Ø7
SC-1 x550 + spare 150  M4.2x19mm	SC-2 x24 + spare 6  M4.2x30mm	SC-3 x7 + spare 3  M4.8x60mm	SC-4 x32 + spare 4  M6x40mm	SC-5 x10 + spare 2  Ø8x80mm
SC-6 x8 + spare 1  Ø12x120mm	SC-7 x8 + spare 2  M6	SC-8 x8 + spare 2  M4.2x30mm	SC-9 x4 + spare 2  M4.2x25mm	SC-10 x4 + spare 2  Ø4.8xØ16x16mm
SU-2 x2 	SU-3 x1 	SU-6 x1  8530	WD1 x1 	WD5 x1 


**Variation 1:
Install of the canopy on the right side**





APPEARANCE & SIZE :






STEP 1 :













Dimension:













STEP 2 : Expansion screws








STEP 3 :








STEP 4 :








STEP 5 :




STEP 6 :




STEP 7 :




STEP 8 :




WP6+UC008-1,2,3 x2




STEP 9 :




STEP 10 :




STEP 11 :




Detail:





STEP 12 :




STEP 13 :




STEP 14 :




STEP 15 :




Detail:




STEP 16 :



STEP 17 :








STEP 18 :









STEP 19 : Connecting Together


A=B=255mm




STEP 20 :Strengthening connections




STEP 21 :




STEP 22 : The installation of top roof panel.




STEP 23 :






STEP 24:









STEP 25 :









STEP 26: DOOR and LOCK





STEP 27 : Connecting Together




STEP 28 :







**Variation 2:
Install of the canopy on the left side**








STEP 1 :












Dimension:











STEP 2 : Expansion screws








STEP 3 :






STEP 4 :




STEP 5 :




STEP 6 :




STEP 7 :




STEP 8 :




STEP 9 :




STEP 10 :




STEP 11 :




Detail:





STEP 12 :








STEP 13 :



STEP 14 :







STEP 15 :












Please pre-drill holes first


Detail:




STEP 16 :





STEP 17 :







STEP 18 :









STEP 19 : Connecting Together







A=B=255mm




STEP 20 :Strengthening connections







STEP 21 :




STEP 22 : The installation of top roof panel.




STEP 23 :






STEP 24:









STEP 25 :









STEP 26: DOOR and LOCK










STEP 27 : Connecting Together



STEP 28 :






The installation of window fastener







Lock point

Optional accessory: Gutter System




(A)		L=2420mm	2
(B)		L=430mm	2
(C)		/	2
(D)		/	1+1
(E)		/	18
(F)		/	1
(G)		L=100mm	2
(H)		L=170mm	2
(I)		L=1780mm	2
(J)		/	6
(K)		/	4
(L)		M4.2x50mm	30
(M)		M4.2x19mm	60
(N)		M4x20mm	12

Installation of Gutter



Installation of drainage pipe



Structural adhesive (not included)

